



NOTE— $\text{am_lock}<\mathbf{x}>$ refers to the received lane \mathbf{x} of the service interface, where $\mathbf{x} = 0:3$ (for 40GBASE-R) or $0:19$ (for 100GBASE-R)

Figure 82–1—Alignment marker lock state diagram