	IEEE 802.16 Broadband Wireless Access Working Group <http: 16="" ieee802.org=""></http:>		
Title	Relay zone indicator		
Date Submitted	2007-0 <u>4</u> 3-0 <u>9</u> 5		
Source(s)	Hyunjeong Kang, Changyoon Oh, Mihyun Lee, HyoungKyu Lim, Jaeweon Cho, Panyuh JooVoice: +82-31-279-5084 Fax: +82-31-279-5130 mailSamsung Electronicsto: changyoon.oh@samsung.com,		
	Rakesh Taori Samsung Adv. Institute of Technology		
Re:	Call for technical Comments and Contributions regarding IEEE project P802.16j		
Abstract	This contribution proposes a signaling method that provides the OFDMA symbol offset of the relay zone.		
Purpose	Discussion and Adoption in IEEE 802.16j		
Notice	This document has been prepared to assist IEEE 802.16. It is offered as a basis for discussion and is not binding on the contributing individual(s) or organization(s). The material in this document is subject to change in form and content after further study. The contributor(s) reserve(s) the right to add, amend or withdraw material contained herein.		
Release	The contributor grants a free, irrevocable license to the IEEE to incorporate material contained in this contribution, and any modifications thereof, in the creation of an IEEE Standards publication; to copyright in the IEEE's name any IEEE Standards publication even though it may include portions of this contribution; and at the IEEE's sole discretion to permit others to reproduce in whole or in part the resulting IEEE Standards publication. The contributor also acknowledges and accepts that this contribution may be made public by IEEE 802.16.		
Patent Policy and Procedures	The contributor is familiar with the IEEE 802.16 Patent Policy and Procedures <http: 16="" ieee802.org="" ipr="" patents="" policy.html="">, including the statement "IEEE standards may include the known use of patent(s), including patent applications, provided the IEEE receives assurance from the patent holder or applicant with respect to patents essential for compliance with both mandatory and optional portions of the standard." Early disclosure to the Working Group of patent information that might be relevant to the standard is essential to reduce the possibility for delays in the development process and increase the likelihood that the draft publication will be approved for publication. Please notify the Chair <mailto:chair@wirelessman.org> as early as possible, in written or electronic form, if patented technology (or technology under patent application) might be incorporated into a draft standard being developed within the IEEE 802.16 Working Group. The Chair will disclose this notification via the IEEE 802.16 web site <htps: 16="" ieee802.org="" ipr="" notices="" patents="">.</htps:></mailto:chair@wirelessman.org></http:>		

Relay zone indicator

Hyunjeong Kang, Changyoon Oh, Mihyun Lee, HyoungKyu Lim, Jaeweon Cho, Panyuh Joo Samsung Electronics

Rakesh Taori Samsung Advanced Institute of Technology

1. Introduction

This contribution proposes a signaling method for indicting the start of relay zone. The proposed signaling method, which was discussed in the March meeting, makes use of the Gap/PAPR reduction IE (DIUC=13) in the DL-MAP. This method uses the boosting field as relay zone indicator for the RS. This signaling takes place in the access zone, at the time of the network entry in such a way that the RS is able to read the start of the relay zone, while the MS continues to process DIUC=13 as Gap/PAPR reduction IE in accordance with the existing specification.

2. Problem Statement

On initialization, it is assumed that a RS performs initial network entry with an access station, i.e., an MR-BS or RS in the same way that an MS does. In the beginning, RS detects a preamble in the MR-BS frame or an RS frame and establishes synchronization with the access station. RS continues to perform the remaining initial network entry procedure in the access zone.

After the RS completes its network entry, to continue communicating with the access station in the relay zone, the RS needs to be informed about the location of the start of the relay zone. This signaling needs to take place in the access zone. So the goal is to design the signaling in such a way that the RS is able to extract the start of t he relay zone while the operation of the MS should remain unaffected.

3. Suggested Remedy

In March meeting, the use of Gap/PAPR reduction IE (DIUC=13) was discussed. The main idea is to indicate the start of the DL relay zone through the use of "OFDMA Symbol offset" field in the GAP/PAPR reduction IE (DIUC=13) and utilize the unused power boosting field (3 bits) as an indicator to the RS that the IE contains information about the start of the Relay zone. The method works as follows: The MR-BS or RS will transmit DIUC=13 to indicate the start of the relay zone using the "OFDMA symbol offset" field. Since DIUC=13 is also transmitted by the MR-BS or RS for Gap/PAPR reduction purposes, it is important to add information which clearly tells the RS when the IE is indicating start of the relay zone. The proposal is to use the bits in the boosting field to signal to the RS that the OFDMA symbol offset field is indicating the location of

the start of the DL relay zone.

Similarly, the MR-BS or RS transmits Safety zone IE (UIUC=13) in the access zone and in the relay zone, so that the MS recognizes the existence of another zone in UL-subframe while the RS can read the location of the start of the UL Relay zone.

In summary, this contribution proposes the following:

- Clarify the operation that indicate Relay zone
 - Use GAP/PAPR reduction IE (DIUC=13) with relay zone indicator set to '1' to indicate that GAP IE (DIUC=13) is being transmitted to indicate the DL Relay zoneOne of boosting field is used as relay zone indicator
 - Use Safety zone IE (UIUC=13) to indicate the uplink of Relay zone.

4. Proposed Text Change

[Insert the following at the end of section 8.4.5.3.4:]

MR-BS or RS shall transmit DIUC=13 in the DL-MAP to indicate the start of the DL Relay zone. The boosting field in DIUC=13 is used as a relay zone indicator. Upon receipt of the DIUC=13 with relay zone indicator in the DL-MAP, the RS shall recognize that the OFDMA symbol offset field is the location of the start of the DL-Relay zone. The MS shall recognize DIUC=13 as Gap/PAPR reduction IE. After the RS moves to the relay zone, the transceiver mode of the relay zone shall be Rx, so that the RS can receive the R-FCH and R-DL-MAP and Relay_Frame_configuration message.

[Change Table 275 as following:]

<u>Syntax</u>	<u>Size</u>	<u>Notes</u>
DL_MAP_IE() {	_	=
DIUC_	<u>4bits</u>	=
<u>if (DIUC == 14) {</u>		=
Extended-2 DIUC dependent IE	_	=
<u>} Else if (DIUC == 15) {</u>	_	=

Extended DIUC dependent IE	<u>variable</u>	See subclauses following 8.4.5.3.1.
<u>} else {</u>		_

<u>Syntax</u>	<u>Size</u>	<u>Notes</u>
$\frac{if(INC_CID == 1)}{!}$	_	The DL-MAP starts with INC_CID =0. INC_CID is toggled between 0 and 1 by the CID- SWITCH_IE() (8.4.5.3.7)
N_CID_	<u>8 bits</u>	Number of CIDs assigned for this IE
<u>for (n=0; n< N_CID; n++) {</u>	_	=
If (included in SUB-DL-UL-MAP) {	=	_
RCID_IE()		For SUB-DL-UL-MAP, reduced CID format is used
<u>} else {</u>	_	=
CID	<u>16 bits</u>	=
1_	—	_
1		
OFDMA Symbol offset	<u>8 bits</u>	
if (Permutation = 0b11 and AMC type is 2x3 or 1x6)) {		
Subchannel offset	<u>8 bits</u>	
<u>Boosting</u>	<u>3 bits</u>	<u>000: normal (not boosted); 001: +6dB; 010: -6dB;</u> <u>011: +9dB; 100: +3dB; 101: -3dB; 110: -9dB;</u> <u>111: -12dB;</u>
<u>No. OFDMA triple symbol</u>	<u>5 bits</u>	Number of OFDMA symbols is given in multiples of 3 symbols
<u>No. Subchannels</u>	<u>6 bits</u>	
<u>} else {</u>		
Subchannel offset	<u>6 bits</u>	
Boosting_	<u>3 bits</u>	000: normal (not boosted); 001: +6dB; 010: -6dB; 011: +9dB; 100: +3dB; 101: -3dB; 110: -9dB; 111: -12dB; 100: Relay zone indicator
No. OFDMA Symbols	<u>7 bits</u>	
No. Subchannels	<u>6 bits</u>	
<u>}</u>		
Repetition Coding Indication	<u>2 bits</u>	0b00 – No repetition coding 0b01 – Repetition coding of 2 used 0b10 – Repetition coding of 4 used 0b11 – Repetition coding of 6 used
<u>}</u>		
1		

[Insert the followings at the end of section 8.4.5.4.7:]

To indicate the start of the UL-Relay zone, the MR-BS or RS shall transmit safety zone IE (UIUC=13) in the access zone. Upon receipt of the safety zone IE, MS recognizes the existence of another zone in the UL subframe. MR-BS or RS shall transmit safety zone IE to RS in the relay zone. Upon receipt of the safety zone IE, the RS shall recognizes the start of the UL relay zone.

References

[1] IEEE 802.16j-07/236, "MAC message for configuring the multi-hop relay frame structure", Samsung Electronics, March 2007.

[2] IEEE 802.16-2005, "IEEE Standard for Local and metropolitan area networks-Part 16: Air Interface for Fixed and Mobile Broadband Wireless Access Systems: Amendment 2: Physical and Medium Access Control Layers for Combined Fixed and Mobile Operation in Licensed Bands and Corrigendum 1.