

Values: TRUE: The requested change to the allocated power is accepted
 FALSE: The requested change to the allocated power is not accepted

33.7.6.5 State diagrams

The general state change procedure for PSEs is shown in Figure 33–27.




Figure 33–27—PSE power control state diagram