

# Comments 195, 196, 197, 198: Link Sync State Diagram

G. Zimmerman / CME Consulting

2/25/2026

Revised 3/9/2026

NOTE: Comment 115 also has bearing on this

# Comments

ID	Commenter	CommenterCo	Subclause	Page	Line	Comment	SuggestedRemedy	
195	Zimmerman, George	CME Consulting/ADI,APL Gp, Cisco, Infineon, OnSemi, Sony	201.5.2.10	120	4	This section describes the link synchronization, but lacks the simple requirement that the state diagram (Figure 201-26) shall be followed.	Change "shall establish the start of PHY PMA training as defined in 201.5.2.7." to "shall conform to the state diagram in Figure 201-26. This section describes and defines the function of Figure 201-26, the link synchronization process."	
197	Zimmerman, George	CME Consulting/ADI,APL Gp, Cisco, Infineon, OnSemi, Sony	201.5.2.10	120	40	The 5th paragraph here has shalls which duplicate what is in the state diagram. They should be replaced by descriptive text.	Replace "shall output" at lines 42 and 44 with "outputs"  Replace "shall repeat" at line 45 with "repeats"  Replace "shall stop outputting and enter" at lines 46-47 with "stops outputting and enters"  Replace "shall also enter" at line 48 with "enters"	
196	Zimmerman, George	CME Consulting/ADI,APL Gp, Cisco, Infineon, OnSemi, Sony	201.5.2.10	120	41	The text here includes a delay for the FOLLOWER sending out a SEND_S pulse that conflicts with the state diagram. Assuming this is the intended behavior, the state diagram needs to be corrected.	<b>SEE THIS PRESENTATION</b>	
198	Zimmerman, George	CME Consulting/ADI,APL Gp, Cisco, Infineon, OnSemi, Sony	201.5.2.10	.1	122	1	The conditions for what TRUE and FALSE mean are contained as 'shalls' in the variable description for send_s_sigdet. Since the state diagram is one 'shall' this makes it a redundant requirement, and isn't good style.	Delete Text (2 sentences) from "At least 3 consecutive... to "setting this variable from TRUE to FALSE".  Change definitions of TRUE and FALSE to:  TRUE: At least 3 consecutive valid SEND_S pulses have been detected. FALSE: No SEND_S pulses have been detected for at least 3.1 us.

# Related Comments

ID	Commenter	Affiliation	Subclause	Page	Line	Comment	SuggestedRemedy
115	Jonsson, Ragnar	Infineon	201.5.2.10.1	122		The description "At least 3.1µs period with no SEND_S pulses detected shall be detected before setting this variable from TRUE to FALSE" can lead to the state machine staying erroneously in the SEND_S state, in the presence of EMI pulses.	Change "At least 3.1µs period with no SEND_S pulses detected shall be detected before setting this variable from TRUE to FALSE" to "If less than three pulses are detected within a 5.1us period, the send_s_sigdet transitions from TRUE to FALSE"


# Problem

- 201.5.2.10 contains both a textual description of the Link Sync Process and the formal description of the State Diagram
  - They do not describe the same behaviour for the progress of detecting the link\_sync until entry to PAUSE
- The text describes its behavior with “shalls”, which are duplicative of the state diagram’s requirements
- SEND\_S is described both as a pulse and as a periodic pulse train
  - The use is different for the LEADER and the FOLLOWER...
- The behavior of the key variable, send\_s\_sigdet, is defined to be dependent on it’s state – mixing definition and state diagram

# Text and State Diagram



When the FOLLOWER detects a sufficient number of the LEADER's SEND\_S pulses to determine that the LEADER is active, the FOLLOWER shall output one SEND\_S pulse 435 +90/-10 ns after the detection of the LEADER's most-recent SEND\_S pulse. For each subsequent SEND\_S pulse detected from the LEADER, the FOLLOWER shall output one SEND\_S pulse with timing as shown in Figure 201-25. This pattern shall repeat until the LEADER detects a sufficient number of the FOLLOWER's SEND\_S pulses to determine that the FOLLOWER is active. Then, the LEADER shall stop outputting SEND\_S pulses and enter the SILENT\_WAIT state as shown in Figure 201-26. Likewise, after the FOLLOWER determines that the LEADER has stopped outputting SEND\_S pulses, the FOLLOWER shall also enter the SILENT\_WAIT state.



# Behavior: Text vs. Diagram

## TEXT

- Leader sends periodic SEND\_S
- Follower detects “a sufficient number” of pulses
- Follower outputs a single SEND\_S pulse with delay
- Follower then outputs a single SEND\_S pulse (with delay) for each subsequent pulse
- When Leader detects “a sufficient number” of follower’s pulses, it enters SILENT\_WAIT state & goes silent
- Follower detects Leader’s silence (unspecified criterion) and moves on to SILENT\_WAIT & goes silent
- Text does not describe further behavior (progress to PAUSE)

## DIAGRAM

- Leader sends SEND\_S with each transmit clock
  - No mention of silence then repeating, is SEND\_S a pulse or a sequence of pulses?
  - Comment 113 would have “SEND\_S signal” & “SEND\_S pulse”
- Follower silently waits to detect 3 consecutive SEND\_S pulses
- Follower then begins sending SEND\_S
  - Overrides delay mentioned in text, and if SEND\_S is a sequence of pulses, this differs from text
- When Leader detects 3 consecutive SEND\_S pulses, enters SILENT\_WAIT state & goes silent
- When Follower misses the first SEND\_S pulse from the Leader, it enters SILENT\_WAIT and goes silent
- Follower will fall straight through SILENT\_WAIT to PAUSE
- Leader will proceed to PAUSE when it misses it’s first Follower SEND\_S pulse

# Desired Behavior and Consequences

- I believe we want the behavior in the text, particularly
  - Follower first detects ‘a sufficient number’ of Leader pulses
  - Follower responds with a single pulse to each subsequent pulse from the Leader, pulse by pulse
  - SEND\_S signal detections (send\_s\_sigdet) is more robust than just consecutive pulses – “a sufficient number”
  - Detecting silence from the partner is more robust than missing a single pulse
- This means:
  - SEND\_S is a pulse (contrary to comment 113)
  - The state diagram needs to generate the periodic pulse train at the Leader
  - We either need a new variable to detect silence, or else states in the diagram to describe the behavior of send\_s\_sigdet

# Comment 115


- Comment 115 changes the transition condition for detecting that the link partner has transitioned to SEND\_Z to detecting a specific number of pulses within a specific time.
- This removes the issue where a single missed pulse can cause a link partner to advance to the next state (or fall through a state)
- The suggested resolution of comment 115 is incorporated into the solution proposed here

# Proposed solution


- Add a new variable for detecting silence (incorporating comment 115) & modify send\_s\_sigdet
  - **quiet\_detect**: A Boolean variable that indicates whether the link partner has ceased sending SEND\_S pulses.  
VALUES:  
TRUE: No SEND\_S pulses have been detected at the specified times (for LEADER or FOLLOWER see Figure 201-25) within the preceding 5.1 usec.  
FALSE: At least one send\_s pulse has been detected at the specified times (for LEADER or FOLLOWER see Figure 201-25) within the preceding 5.1 usec
  - **send\_s\_sigdet**: A Boolean variable indicating whether sufficient SEND\_S pulses have been detected. The definition of a sufficient number of pulses is implementation dependent.  
VALUES:  
TRUE: Sufficient SEND\_S pulses have been detected  
FALSE: Sufficient SEND\_S pulses have not been detected
- Other new variables: single\_send\_s\_detect
- Add new timers: follower\_delay\_timer, leader\_pause\_timer, pulse\_timer
- Delete “shalls” in the descriptive text of 201.5.2.10

# Proposed diagram: TRANSMIT\_DISABLE exit to PAUSE entry

## Leader



## Follower



These two state chains go (as parallel vertical branches) replacing the states in the blue square in the PHY Link Synchronization state diagram at right.





Figure 201–26—PHY Link Synchronization state diagram

# Modified Description Text and State Diagram

When the FOLLOWER detects a sufficient number of the LEADER's SEND\_S pulses to determine that the LEADER is active, the FOLLOWER outputs one SEND\_S pulse 435 +90/-10 ns after the detection of the LEADER's most-recent SEND\_S pulse. For each subsequent SEND\_S pulse detected from the LEADER, the FOLLOWER outputs one SEND\_S pulse with timing as shown in Figure 201-25. This pattern repeats until the LEADER detects a sufficient number of the FOLLOWER's SEND\_S pulses to determine that the FOLLOWER is active. Then, the LEADER enters the SILENT\_WAIT state and stops transmitting SEND\_S pulses as shown in Figure 201-26. Likewise, after the FOLLOWER determines that the LEADER has stopped transmitting SEND\_S pulses, the FOLLOWER also enters the SILENT\_WAIT state.



# Variables & Timers

## Variables

### quiet\_detect

A Boolean variable indicating whether the link partner has ceased sending SEND\_S pulses.

- TRUE: No SEND\_S pulses have been detected at the specified times (for LEADER or FOLLOWER see Figure 201–25) within the preceding 5.1  $\mu$ sec.
- FALSE: At least one send\_s pulse has been detected at the specified times (for LEADER or FOLLOWER see Figure 201–25) within the preceding 5.1  $\mu$ sec.

### send\_s\_sigdet

A Boolean variable indicating whether sufficient SEND\_S pulses were detected with proper spacing. The definition of a sufficient pulses is implementation dependent.

Values:

- TRUE: Sufficient SEND\_S pulses have been detected.
- FALSE: Sufficient SEND\_S pulses have not been detected.

### single\_send\_s\_detect

A Boolean variable indicating whether a SEND\_S pulse has been detected.

Values:

- TRUE: SEND\_S pulse detected.
- FALSE: No SEND\_S pulse detected.

## Timers

### follower\_delay\_timer

This timer is used to control the offset between the FOLLOWER detecting a SEND\_S pulse from the LEADER and the FOLLOWER transmitting its SEND\_S pulse reply as shown in Figure 201-25. Duration: 435 +90/-10 nsec.

### leader\_pause\_timer

This timer is used to control the quiet time between SEND\_S pulses from the LEADER. Duration: 116 DME symbol times (990.867 nsec).

### link\_fail\_inhibit\_timer

see 98.5.2

(existing)

### pulse\_timer

This timer is used to output the SEND\_S pulse. Duration: 4 DME symbol times (33.133 nsec).

Questions?  
Thank you.