Project	IEEE 802.16 Broadband Wireless Access Working Group <a href="http://ieee802.org/16">http://ieee802.org/16</a> >
Title	FCAPS based structure for Mobile MIB, IEEE 802.16i
Date Submitted	2006-09-17
Source(s)	Eero Wallenius, Ph.D., Nokia Oyj, E-mail: eero.wallenious@nokia.com
	Marko Siiskonen, Nokia Oyj, E-mail: marko.siiskonen@nokia.com
	Mikko Kylväjä, Nokia Oyj, E-mail: mikko.kylvaja@nokia.com
Re:	Comment on P802.16i-06/001r3
Abstract	This contribution proposes the modification of the Mobile MIB 802.16i structures based on FCAPS model where applicable to clarify the differentiate the different tasks, related functionalities and their detailed FCAPS properties, parameters, counters gauges.
Purpose	Adoption
Notice	This document has been prepared to assist IEEE 802.16. It is offered as a basis for discussion and is not binding on the contributing individual(s) or organization(s). The material in this document is subject to change in form and content after further study. The contributor(s) reserve(s) the right to add, amend or withdraw material contained herein.
Release	The contributor grants a free, irrevocable license to the IEEE to incorporate material contained in this contribution, and any modifications thereof, in the creation of an IEEE Standards publication; to copyright in the IEEE's name any IEEE Standards publication even though it may include portions of this contribution; and at the IEEE's sole discretion to permit others to reproduce in whole or in part the resulting IEEE Standards publication. The contributor also acknowledges and accepts that this contribution may be made public by IEEE 802.16.
Patent Policy and Procedures	The contributor is familiar with the IEEE 802.16 Patent Policy and Procedures <a href="http://ieee802.org/16/ipr/patents/policy.html">http://ieee802.org/16/ipr/patents/policy.html</a> , including the statement "IEEE standards may include the known use of patent(s), including patent applications, provided the IEEE receives assurance from the patent holder or applicant with respect to patents essential for compliance with both mandatory and optional portions of the standard." Early disclosure to the Working Group of patent information that might be relevant to the standard is essential to reduce the possibility for delays in the development process and increase the likelihood that the draft publication will be approved for publication. Please notify the Chair <a href="mailto:chair@wirelessman.org">mailto:chair@wirelessman.org</a> as early as possible, in written or electronic form, if patented technology (or technology under patent application) might be incorporated into a draft standard being developed within the IEEE 802.16 Working Group. The Chair will disclose this notification via the IEEE 802.16 web site <a href="http://ieee802.org/16/ipr/patents/notices">http://ieee802.org/16/ipr/patents/notices</a> .

## 1. Introduction

The purpose of the restructuring is to clarify the structure of the WiMax Mobile MIB according to TMF defined FCAPS model (FM, CM, AM, PM and SM). This would enable to insert and locate individual category group and item more easily and the MIB would be more readable by the people designing and implementing their part of the system as people usually dealing with each of the categories are different and the development processes are quite separated with each other.

All future contribution should following this basic cource. Additional subcategories can be added as needed and main categories not needed may be left out when applicaple.

# 2. Proposed Text Changes

Substitute from line 3 page 280 to line 30 page 289 with the following text (starting from next page)

```
wmaxIfBsFmMobility OBJECT IDENTIFIER ::= {wmanIfBsFmObjects x} -- e.g. x=0
wmaxIfBsCmMobility OBJECT IDENTIFIER ::= {wmanIfBsCmObjects x} -- e.g. x=7
wmaxIfBsAmMobility OBJECT IDENTIFIER ::= {wmanIfBsAmObjects x} -- e.g. x=0
wmaxIfBsPmMobility OBJECT IDENTIFIER ::= {wmanIfBsPmObjects x} -- e.g. x=0
wmaxIfBsSmMobility OBJECT IDENTIFIER ::= {wmanIfBsSmObjects x} -- e.g. x=0
wmaxIfMsFmMobility OBJECT IDENTIFIER ::= {wmanIfBsFmObjects x} -- e.g. x=0
wmaxIfMsCmMobility OBJECT IDENTIFIER ::= {wmanIfBsCmObjects x} -- e.g. x=0
wmaxIfMsAmMobility OBJECT IDENTIFIER ::= {wmanIfBsAmObjects x} -- e.g. x=0
wmaxIfMsPmMobility OBJECT IDENTIFIER ::= {wmanIfBsPmObjects x} -- e.g. x=0
wmaxIfMsSmMobility OBJECT IDENTIFIER ::= {wmanIfBsSmObjects x} -- e.g. x=0
wmanIfBsCmHOConfiguration OBJECT IDENTIFIER ::= { wmanIfBsCmMobility 2}
wmaxIfBsCmMobilityOperatorId OBJECT-TYPE
             SYNTAX Integer32
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                          "An unique operator identifier."
             ::= { wmanIfBsCmHOConfiguration 1 }
wmaxIfBsCmMobilityBsId OBJECT-TYPE
             SYNTAX WmanIfBsIdType
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                          "An unique BS identifier."
             ::= { wmanIfBsCmHOConfiguration 2 }
wmaxIfBsCmHOSupport OBJECT-TYPE
             SYNTAX BITS
                          MDHO/FBSS HO not supported(0),
                          FBSS/MDHO DLRF combining supported(1),
                          MDHO DL soft combining supported monitoring single MAP from anchor BS(2),
                          MDHO DL soft combining supported monitoring MAPS from active BSs(3),
                          reserved1(5),
                          reserved2(6),
                          reserved3(7)
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                          "The Handover supported field indicates what type(s) of HO the BS and the MS
             supports."
             ::= { wmanIfBsCmHOConfiguration 3 }
wmaxIfBsCmHOResourceRetainTime OBJECT-TYPE
             SYNTAX Integer32
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                          "The Resource Retain Time is the duration for MS s connection information
             that will be retained in serving BS. BS shall start Resource Retain Time timer at MS notification
             of pending HO attempt through MOB HO-IND or by detecting an MS drop. The unit of this value
             is 100 milliseconds."
             ::= { wmanIfBsCmHOConfiguration 4 }
wmaxIfBsCmHOProcessOptimizationMSTimer OBJECT-TYPE
```

SYNTAX INTEGER

```
MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "The duration in frames MS shall wait until receipt
             of the next unsolicited network re-entry MAC management message as indicated in the HO Process
             Optimization element of the RNG-RSP message"
             ::= { wmanIfBsCmHOConfiguration 5 }
wmaxIfBsCmHORetransmissionTimer OBJECT-TYPE
             SYNTAX INTEGER
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "After a MS transmits MOB MSHO-REQ to initiate a handover process, it shall
             start MS Handover Retransmission Timer and shall not transmit another MOB_MSHO-REQ until
             the expiration of the MS Handover Retransmission Timer."
             ::= { wmanIfBsCmHOConfiguration 6 }
wmaxIfBsCmHOMobilityModeSupport OBJECT-TYPE
             SYNTAX BITS
                           handover support(0),
                           sleep-mode support(1),
                           idle-mode support(2)
                           }
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is to represent the supported mobility mode."
             ::= { wmanIfBsCmHOConfiguration 7 }
wmaxIfBsCmHOMsConnectProcessingTime OBJECT-TYPE
             SYNTAX INTEGER
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "Time in ms the MS needs to process information on connections provided in RNGRSP or
             REG-RSP message during HO."
             ::= { wmanIfBsCmHOConfiguration 8 }
wmaxIfBsCmHOMsTekProcessingTime OBJECT-TYPE
             SYNTAX INTEGER
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "Time in ms the MS needs to completely process TEK information during HO."
             ::= { wmanIfBsCmHOConfiguration 9 }
wmaxIfBsCmHOULPermutationBase OBJECT-TYPE
             SYNTAX OCTET STRING
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is used for uplink subcarrier allocation."
             ::= { wmanIfBsCmHOConfiguration 10 }
wmaxIfBsCmHODLPermutationBase OBJECT-TYPE
             SYNTAX OCTET STRING
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is used for downlink subcarrier allocation."
             ::= { wmanIfBsCmHOConfiguration 11 }
```

```
wmaxIfBsCmHOPreambleIndex OBJECT-TYPE
            SYNTAX OCTET STRING
            MAX-ACCESS read-write
            STATUS current
            DESCRIPTION
                          "This parameter is used for downlink synchronization by MS."
            ::= { wmanIfBsCmHOConfiguration 12 }
wmaxIfBsCmHOSegmentNumber OBJECT-TYPE
            SYNTAX INTEGER
            MAX-ACCESS read-write
            STATUS current
            DESCRIPTION
                          "This parameter is an unique segment identifier ."
            ::= { wmanIfBsCmHOConfiguration 13 }
wmaxIfBsCmAdjacencyNeighbourBsTable OBJECT-TYPE
            SYNTAX SEQUENCE OF WmanIfNeighbourBsEntry
            MAX-ACCESS not-accessible
            STATUS current
            DESCRIPTION
                          "This table contains neighbouring BS
            ::= { wmanIfBsCmHOConfiguration 14 }
wmaxIfBsCmAdjacencyNeighbourBsEntry OBJECT-TYPE
            SYNTAX WmanIfNeighbourBsEntry
            MAX-ACCESS not-accessible
            STATUS current
            DESCRIPTION
                          "This table is indexed by wmanIfNeighbourBsId."
            INDEX { ifIndex, wmanIfNeighbourBsId }
            ::= { wmanIfBsCmAdjacencyNeighbourBsTable 1 }
wmaxIfBsCmAdjacencyNeighbourBsId OBJECT-TYPE
            SYNTAX WmanIfBsIdType
            MAX-ACCESS read-write
            STATUS current
            DESCRIPTION
                          "The neighbouring BS identifier."
            ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 1 }
wmaxIfBsCmAdjacencyNeighbourBsFAIndex OBJECT-TYPE
            SYNTAX INTEGER
            MAX-ACCESS read-write
            STATUS current
            DESCRIPTION
                          "Frequency Assignment Index."
            ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 2 }
wmaxIfBsCmAdjacencyNeighbourBsEIRP OBJECT-TYPE
            SYNTAX INTEGER (-128..127)
            MAX-ACCESS read-write
            STATUS current
            DESCRIPTION
                          "Neighbour BS EIRP."
            ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 3 }
wmaxIfBsCmAdjacencyNeighbourBsHOProcessOptimization OBJECT-TYPE
            SYNTAX Integer32
```

MAX-ACCESS read-write

STATUS current

```
DESCRIPTION
                            "Identifies re-entry process management current HO attempt due to the availability of
             MS service and operational status post-HO
             ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 4 }
wmaxIfBsCmAdjacencyNeighbourBsSchedulingServiceSupport OBJECT-TYPE
             SYNTAX BITS
                           real-time polling service(0),
                           extended real-time polling service(1),
                           non-real-time polling service(2),
                           unsolicited grant service(3),
                           best effort(4)
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is used to indicate neighbouring BS scheduling service type."
             ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 5 }
wmaxIfBsCmAdjacencyNeighbourBsBandwidth OBJECT-TYPE
             SYNTAX Integer32
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is used to indicate neighbouring BS bandwidth."
             ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 6 }
wmaxIfBsCmAdjacencyNeighbourBsFFTSize OBJECT-TYPE
             SYNTAX Integer32
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is used to indicate neighbouring BS FFT size."
             ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 7 }
wmaxIfBsCmAdjacencyNeighbourBsCyclePrefix OBJECT-TYPE
             SYNTAX Integer32
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is used to indicate neighbouring BS Cycle prefix."
             ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 8 }
wmaxIfBsCmAdjacencyNeighbourBsFrameDurationCode OBJECT-TYPE
             SYNTAX Integer32
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is used to indicate neighbouring BS Frame duration code."
             ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 9 }
wmaxIfBsCmAdjacencyNeighbourBsULPermutationBase OBJECT-TYPE
             SYNTAX Integer32
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is used to indicate neighbouring BS uplink permutation base."
             ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 10 }
wmaxIfBsCmAdjacencyNeighbourBsDLPermutationBase OBJECT-TYPE
```

SYNTAX Integer32

```
MAX-ACCESS read-
             STATUS current
             DESCRIPTION
                           "This parameter is used to indicate neighbouring BS downlink permutation base."
             ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 11 }
wmaxIfBsCmAdjacencyNeighbourBsSegmentNumber OBJECT-TYPE
             SYNTAX Integer32
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is used to indicate neighbouring BS segment number."
             ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 12 }
wmaxIfBsCmAdjacencyNeighbourBsPreambleIndex OBJECT-TYPE
             SYNTAX Integer32
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is used to indicate neighbouring BS preamble index."
             ::= { wmanIfBsCmAdjacencyNeighbourBsEntry 13 }
wmanIfBsCmPagingGroupTable OBJECT-TYPE
             SYNTAX SEQUENCE OF WmanIfBsPagingGroupEntry
             MAX-ACCESS not-accessible
             STATUS current
             DESCRIPTION
                           "This table contains paging group related parameters."
             ::= { wmanIfBCmMobility 3 }
wmaxIfBsCmPagingGroupEntry OBJECT-TYPE
             SYNTAX WmanIfBsPagingGroupEntry
             MAX-ACCESS not-accessible
             STATUS current
             DESCRIPTION
                           "This table is indexed by wmanIfBsPagingGroupId."
             INDEX { wmanIfBsPagingGroupId }
             ::= { wmanIfBsCmPagingGroupTable 1 }
wmanIfBsCmPagingGroupEntry ::= SEQUENCE {
wmanIfBsCmPagingControlId IpAddress,
wmanIfBsCmPagingGroupId INTEGER,
wmanIfBsCmMgmtResourceHoldingTimerInteger32,
wmanIfBsCmT46Timer Integer32,
wmanIfBsCmPagingRetryCount INTEGER,
wmanIfBsCmREQDuration INTEGER,
wmanIfBsCmMACHashSkipThresholdInteger32,
wmanIfBsCmCDMATransmissionOpportunityAssignmentINTEGER,
wmanIfBsCmPagingResponseWindow INTEGER,
wmanIfBsCmIdleModeTimer INTEGER,
wmanIfBsCmIdleModeSystemTimer INTEGER,
wmanIfBsCmPagingIntervalLength INTEGER,
wmanIfBsCmPagingCycle INTEGER
wmaxIfBsCmPagingControlId OBJECT-TYPE
             SYNTAX IpAddress
             MAX-ACCESS read-write
             STATUS current
             DESCRIPTION
                           "This parameter is used to indicate paging controller identifier connected by BS."
             ::= { wmanIfBsCmPagingGroupEntry 1 }
```

#### wmaxIfBsCmPagingGroupId OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"This parameter is used to indicate the paging group identifier assigned to BS by

network."

::= { wmanIfBsCmPagingGroupEntry 2 }

#### wmaxIfBsCmPagingMgmtResourceHoldingTimer OBJECT-TYPE

SYNTAX Integer32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Time the BS maintain connection information with the MS after the

BS send DREG-CMD to the MS"

::= { wmanIfBsCmPagingGroupEntry 3 }

#### wmaxIfBsCmPagingT46Timer OBJECT-TYPE

SYNTAX Integer32

MAX-ACCESS read-write

STATUS current

**DESCRIPTION** 

"Time the BS waits for DREGREQ in case of unsolicited Idle Mode initiation from BS."

::= { wmanIfBsCmPagingGroupEntry 4 }

### wmaxIfBsCmPagingRetryCount OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Number of retries on paging transmission. If the BS does not receive RNG-REQ from the MS until this value decreases to zero, it determines that the MS is unavailable."

::= { wmanIfBsCmPagingGroupEntry 5 }

#### wmaxIfBsCmPagingREQDuration OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Waiting value for the DREG-REQ message re-transmission (measured in frames)."

::= { wmanIfBsCmPagingGroupEntry 6 }

#### wmaxIfBsCmPagingMACHashSkipThreshold OBJECT-TYPE

SYNTAX Integer32

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Maximum number of successive MOB\_PAG-ADV messages that may be sent from a BS without individual notification for an MS for which BS is allowed to skip MS MAC Address Hash when the Action Code for the MS is 0b00,'No Action Required'."

::= { wmanIfBsCmPagingGroupEntry 7 }

#### wmaxIfBsCmPagingCDMATransmissionOpportunityAssignement OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"The CDMA code and transmission opportunity assignment field indicates the assigned code and transmission opportunity for a MS who is paged to use over dedicated CDMA ranging region."

::= { wmanIfBsCmPagingGroupEntry 8 }

#### wmaxIfBsCmPagingResponseWindow OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

**DESCRIPTION** 

"The Page-Response Window indicates the Page-Response window for a MS who is paged to transmit the assigned code for CDMA ranging channel."

::= { wmanIfBsCmPagingGroupEntry 9 }

### wmaxIfBsCmPagingIdleModeTimer OBJECT-TYPE

SYNTAX INTEGER (128..65536)

MAX-ACCESS read-write

STATUS current

**DESCRIPTION** 

 $"MS \ timed \ interval \ to \ conduct \ Location \ Update. \ Set \ timer \ to \ MS \ Idle \ Mode \ Timeout \ capabilities \ setting. \ Timer \ recycles \ on \ successful \ Idle \ Mode \ Location \ Update."$ 

::= { wmanIfBsCmPagingGroupEntry 10 }

#### wmaxIfBsCmPagingIdleModeSystemTimer OBJECT-TYPE

SYNTAX INTEGER (128..65536)

MAX-ACCESS read-write

STATUS current

**DESCRIPTION** 

"For BS acting as Paging Controller, timed interval to receive notification of MS Idle Mode Location Update. Set timer to MS Idle Mode Timeout. Timer recycles on successful Idle Mode Location Update."

::= { wmanIfBsCmPagingGroupEntry 11 }

## wmaxIfBsCmPagingIntervalLength OBJECT-TYPE

SYNTAX INTEGER (2..5)

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Time duration of Paging Interval of the BS."

::= { wmanIfBsCmPagingGroupEntry 12 }

## wmaxIfBsCmPagingCycle OBJECT-TYPE

SYNTAX INTEGER

MAX-ACCESS read-write

STATUS current

DESCRIPTION

"Cycle in which the paging message is transmitted within the paging group."

::= { wmanIfBsCmPagingGroupEntry 13 }