

## Updated Comment and Remedy for #210 Clause 33.6.3.4, Page 184 line 9. (See Table 1 below for details)

Related to comments:

[#296](#)

[#312](#)

[#239](#)

Figure 33-50 is about DLL PD power control state diagram and can be used for Type 1, Type 2 PDs and Type 3 and 4 single-signature PDs if some modifications will be implemented.

1. `pse_dll_power_type` is used by Figure 33-2 and Figure 33-50 but is missing from Figure 33-2 variable list (33.3.3.7) and from Figure 33-50 variable list (33.6.3.3).
2. `pse_power_type` is used by Figure 33-50 but is missing from Figure 33-50 variable list.
3. `pse_dll_power_level` is not used in Figure 33-2 and Figure 33-50. Delete `pse_dll_pwr_level` from 33.3.3.7 (PD single-signature Type 3/4 variable list) and in 33.6.3.3 (DLL state machine variable list) pages 127 and 181.
4. `pse_power_level` is not used in Figure 33-50 or Figure 33-49 but appears in 33.6.3.3.
5. Variable `pd_dll_power_type` is not used in PSE state diagrams but it appears in 33.2.5.9 (page 69).

### **Proposed Remedy:**

1. Copy `pse_dll_power_type` definition from 33.3.3.3 into 33.3.3.7 and 33.6.3.3 and modify it to include Type 3 and 4 PSEs as follows:

`pse_dll_power_type`

A control variable output by the PD power control state diagram (Figure 33-50) that indicates the PSE type as 1 or 2, see 79.3.2.4.1.

Values:

- 1: The PSE is a Type 1 PSE, for a Type-1 PSE (Default).
- 2: The PSE is a Type 2 PSE, for a Type 2, 3 and, 4 PSE

2. Copy `pse_power_type` variable from 33.3.3.3 into 33.6.3.3 and add to it PSE type 3 and 4 as follows:

`pse_power_type`

A control variable that indicates to the PD the type of PSE by which it is being powered.

Values:

- 1: The PSE is a Type 1 PSE.
- 2: The PSE is a Type 2 PSE or Type 3 PSE or Type 4 PSE.

3. Delete `pse_dll_pwr_level` from 33.3.3.7 (PD single-signature Type 3 and 4 variable list) and in 33.6.3.3 (DLL state machine variable list) pages 127 and 181.
4. Remove `pse_power_level` from 33.6.3.3.
5. Delete Variable `pd_dll_power_type` from 33.2.5.9 (page 69).

6. If group believes that Table 33-40 need to be updated for pd\_dll\_power\_type for Type 3 and 4 then add the following : “Editor Note: Table 33-40 need to be updated for pd\_dll\_power\_type for Type 3 and 4 for pse\_dll\_power\_type for Type 3 and 4.

Proposed Remedy ends here.  
See below details in Table 1.

**Table 1 : D2.0 variable list and where it used.**

#	See Proposed Remedy item #	Variable Name	Generate by	Variable location at							
				PD TYPE				PSE TYPE			
				Type 1/2 variable list/SM (33.3.3.3)	Type 3/4 variable list / SM (33.3.3.7)	Figure 33-50	Figure 33-50 variable list (33.6.3.3)	Type 1/2 variable list/SM (33.2.5.4)	Type 3/4 variable list/SM (33.2.5.9)	Figure 33-49	Figure 33-49 variable list (33.6.3.3)
1	No changes are required	pd_dll_power_type	PSE DLL SM (Figure 33-49)	NO/NO	NO/NO	YES	YES	YES/YES	YES <sup>5</sup> /NO	YES	YES
2	<b>1</b>	pse_dll_power_type	PD DLL SM	YES/YES	NO <sup>1</sup> / YES	YES	NO <sup>1</sup>	NO/NO	NO/NO	NO	NO
3	<b>2</b>	pse_power_type	PD SM	YES/YES	NO/NO	YES	NO <sup>2</sup>	NO/NO	NO/NO	NO	NO
4	<b>3</b>	pse_dll_power_level	PD DLL SM	NO/NO	YES <sup>3</sup> /NO	NO	YES <sup>3</sup>	NO/NO	NO/NO	NO	NO
5	<b>4</b>	pse_power_level	PD DLL SM	NO/NO	YES/YES	NO	YES <sup>4</sup>	NO/NO	NO/NO	NO	NO