

Downshift State Diagram Issues

1/15/2026

G. Zimmerman

CME Consulting/

(ADI, APL Group, Cisco, Infineon, OnSemi, Sony)

Overview

- State diagram in 98D.2 has functional issues, at least:
 - Stuck in DS_INIT state
 - Open ended transition into DS_INIT on mr_autoneg_enable & mr_ds_downshift_enabled
 - Can never go to DS_UPSHIFT
 - upshift_timer is stopped before waiting for a transition...
 - Can never go to DS_RESTART
 - restart_timer is stopped before waiting for a transition...
 - ds_downshift_timer doesn't work – stopped right after started
 - ds_downshift_timer_done is never tested, perhaps “_running” might be a function of !done.
- Could be more....

Figure 98D-1 Downshift state diagram




Figure 98D-1—Downshift state diagram

DISCUSSION?

Thank you!