QCN: Algorithm for P-code

Abdul Kabbani, Rong Pan, Balaji Prabhakar and Mick Seaman


Outline

- Two items to be discussed
 - 1. SONAR/Fb99 approaches
 - Sensitivity of probing for available bandwidth
 - Complexity of having timer at switch (issue raised at Atlanta)
 - 2. Timer-supported basic QCN
 - Adapts the drift timer at the source
 - This gives low recovery time in addition to stability
 - P-code will be posted by Rong after call

Recall: SONAR and Fb99

- In SONAR and Fb99
 - A source (RL) performs an endless loop of FR and AI; meanwhile, it is also probing for "available bandwidth"
 - Switches detect "bandwidth availability" based on queue going down "for a while"; timer used at the switch
 - When bandwidth becomes available on all paths fed by an RL
 - RL goes into Hyper AI


Recall: The SONAR Algorithm at RL




Remarks


- The RL can be in one of 3 states: FR, AI or HAI
- SONAR and Fb99 put HAI *in parallel* with FR and AI
 - That is, when bandwidth availability is detected, RL goes into HAI
 - It does not send any further packets in FR and AI modes
- The parallel structure achieved
 - Stability: Safe operation of RL during congestion: endless loop of FR--AI
 - Rapid response: Because of HAI triggered by a *timer*
- But there is a lot of sensitivity to correctly detecting "bandwidth availability"
 - We will see that it is not an easy condition to detect, esp for 2 sources and large RTT
- Conclusion: Place HAI *in series* with FR and AI for safe operation
 - In order to achieve rapid response use a timer at RL in addition to byte-counter

Basic QCN: FR--Al Rates







Basic QCN: FR--Al Queue sizes




QCN with SONAR HAI makes rate loss more severe




Simulation Time



4srcs, rate




4srcs, qsize



Summary

- "Bandwidth availability" tricky to detect
 - Going into HAI based on incorrect detection degrades performance
- Need to put HAI in series with FR and AI
 - This ensures stability
- Need to use a timer at the source
 - This ensures quick recovery of bandwidth

Timer-supported QCN



- Byte-Counter
 - 5 cycles of FR (150KB per cycle)
 - AI cycles afterwards (75KB per cycle)
 - Fb < 0 sends timer to FR

• RL

- In FR if *both* byte-ctr and timer in FR
- In AI if only one of byte-ctr or timer in AI
- In HAI if *both* byte-ctr and timer in AI
- Note: RL goes to HAI only after 500 pkts have been sent
- Timer
 - 5 cycles of FR (T msec per cycle)
 - AI cycles afterwards (T/2 msec/cycle)
 - Fb < 0 sends timer to FR

Rate Adjustments

When RL is in FR

- Upon completion of a byte-ctr or timer cycle: CR=(CT+TR)/2
- EFR and Target rate reduction enabled during first cycle of byte-ctr

When RL is in Al

- Upon completion of byte-ctr or timer cycle: $TR = TR + R_{AI}$; CR = (CR+TR)/2

(We've used $R_{AI} = 5$ Mbps)

When RL is in HAI

(This means at least 500 pkts have been transmitted since last ding)


- Events = completion of byte-ctr or timer cycles
- Events numbered i = 1, 2, ...
- At the end of event number i: TR = TR + (i*R_{HAI}); CR = (CT+TR)/2;

(We've used $R_{HAI} = 50$ Mbps)


Simulations: OG Hotspot

Parameters


- 10 sources share a 10 G link, whose capacity drops to 0.5G during 2-4 secs
- Max offered rate per source: 1.05G
- RTT = 50 usec
- Buffer size = 100 pkts (150KB); Qeq = 22
- T = 10 msecs
- R_{AI} = 5 Mbps
- R_{HAI} = 50 Mbps




Recovery Time



Stability (RTT = 50 usecs)




Stability (RTT = 50 usecs)




17


Stability (RTT = 50 usecs)



Stability (long RTT = 500 usecs)




Stability (RTT = 500 usecs)



20

Stability (500 usecs)



21

Conclusion

- Discussed trickiness of detecting available bandwidth
- Need to put HAI *in series* with FR and AI
 - Gives good stability; timer gives good recovery time
- Timer-supported QCN
 - Key ideas and features
 - Transmit 500 pkts before going to HAI
 - · Byte-ctr gives network sufficient opportunity to send feedback to RL
 - Timer hastens recovery for slow rate sources
 - No change to switch operation from basic QCN; esp no timer at switch
 - Parameter free (no dynamic parameter choice needed)
 - Very similar to basic QCN
 - Can be further enhanced, e.g. with Fb-hat or Fb99
 - Need to seriously consider benefits of enhancements first!