Considering all Noise Sources over a single data and power pair

IEEE802.3bu Task Force

Jan 2014 Indian Wells, CA

Yair Darshan, Microsemi ydarshan@microsemi.com





- To introduce potential noise sources over a single data pair delivering power and data simultaneously.
- Using the above data to specify later the PSE Differential and common mode noise.

en(f) = Maximum Noise vs. Frequency Requirement



 We need to know the maximum rms noise. On as function of frequency in which data specification is met.

EMI noise source



EMI is one of the noise sources that generate DM noise

Power source and load noise sources



 If power is delivered over the same data pair, we have additional noise sources at near end (power supply noise) and far end (load noise e.g. PD DC/DC converter noise)

More about Power Source Noise



Proposed general case for noise sources - 1



- Output is the noise generated by the return loss during transmission.
- Cother is other noise sources that we may add to the list including design margin

Proposed general case for noise sources - 2

Working assumptions

- *On as function of frequency i.e. On(f) in which data specification is met. The same applies for the other noise sources.*
- Cemi on both ends is the same quantity
- **CPS and CPD are independent noise sources**
- **C**RL on both sides is the same quantity
- **Cother is unknown noise source or a design margin**
- **a**k is the <u>total</u> weight factor and is a function of frequency as well.
- As a result, for different weight per noise source and for k noise sources:

$$e_n^2 \ge \sum_{i=1}^k a_k e_k^2 \qquad \sum_{i=1}^5 a_k = 1$$

In our example we will have:

$$e_{n}^{2} \geq a_{1}e_{emi}^{2} + a_{2}e_{ps}^{2} + a_{3}e_{pd}^{2} + a_{4} \cdot e_{RL}^{2} + a_{5} \cdot e_{other}^{2} + a_{6} \cdot e_{other}^{2}$$

Proposed general case for noise sources - 3

 For the example shown with 6 noise sources, If all noise sources are with the <u>same weight</u> (noise budget is equally distributed between all noise sources for simplified what-if analysis):

$$e_n(f)^2 \ge = 6 \cdot e(f)^2 \quad \rightarrow e_{n_rms}(f) \le \frac{e(f)}{\sqrt{6}} = 0.4 \cdot e_n(f)$$

Each noise source at any given frequency, will need to be ~8dB lower

than **e**n(f) which is the noise limit to meet data integrity.

The general case for the simplified equal weight case would be:

$$e_{rms}(f) \leq \frac{e_n(f)}{\sqrt{k}}$$
 which is $20 \cdot \log\left(\frac{1}{\sqrt{k}}\right)$ below en(f).

More about the evaluation of spec limits - 4

- There are other ways to plug in the design margin.
- The straight forward way for us (per the previous slides) is:
 - RTPGE to deliver the noise mask required to meet data integrity.
 - If the noise mask is due to only EMI noise source, this would be the en(f). Then we need to get from RTPG our budget (our weight) assuming RTPGE take in account all noise sources.
 - Our budget will be equally distributed for PSE and PD budget.
 - The result is PSE and PD noise mask.

Summary

- Based on en(f) (differential and common mode noise data) given from the RTPGE group, we can define the PSE and PD noise requirements.
- For the RTPGE group: There are additional noise to the EMI noise such as PSE and PD noise that need to be considered in the total maximum DM and CM noise requirements.

Proposed next steps

- To ask RTPGE group for channel noise requirements, EMI masks etc. or to define for us their noise requirements to meet their data integrity requirements. (*en(f)* test data).
- It is highly practical from power source and load point of view, to define a detailed table of differential and CM noise per frequency over the frequency range of interest.
- It is important to define the noise also for low frequencies outside the data range from 1-2Hz to 1-10MHz. It will allow more flexibility and cost effective power source when power over data will be implemented.

Proposed text/table for the specification

The following noise limits shall be met at the output of the PSE (see item 5)

ltem	Parameter	Symbol	Unit	Min	Мах	TBD	Additional Information		
1	Output Voltage in the TBD1 state	TBD	V	TBD	TBD	TBD	TBD		
2	Output Voltage in the TBD2 state	TBD	V	TBD	TBD	TBD	TBD		
3	Output Voltage in the Power_ON state	Vport_PSE	V	TBD	TBD	TBD	TBD		
4	Voltage transient below VPort_PSE min.	KTran_lo	%	TBD	TBD	TBD	TBD		
5	Power feeding ripple and noise Vpp								
	f <f1< td=""><td></td><td rowspan="2">Vpp</td><td>TBD</td><td>TBD</td><td></td><td rowspan="6">TBD</td></f1<>		Vpp	TBD	TBD		TBD		
	f1 to f2			TBD	TBD				
	f2 to f3			TBD	TBD				
	f3 to f4			TBD	TBD				
	f4 to f5			TBD	TBD				
	F(n-1) 6 to f(n)			TBD	TBD				
6	Continuous output current capability in POWER_ON state	lcon	A	TBD	TBD	TBD	TBD		
7	Output current in POWER_UP state	linrush	А	TBD	TBD	TBD	TBD		
8	Inrush time	Tinrush	S	TBD	TBD	TBD	TBD		

Proposed text/table for the specification

ltem	Parameter	Symbol	Unit	Min	Max	TBD	Additional Information
12	Output Current at short Circuit	ILIM	A	TBD	TBD	TBD	TBD
13	Short circuit time limit	TLIM	S	TBD	TBD	TBD	TBD
14	Continuous output current capability in POWER_ON state	Icon	A	TBD	TBD	TBD	TBD
15	Output current in POWER_UP state	linrush	A	TBD	TBD	TBD	TBD
16	Inrush time	Tinrush	S	TBD	TBD	TBD	TBD
17	Continuous output power capability in POWER_ON state	Pcon	W	TBD	TBD	TBD	TBD
18	Power turn on time	Tpon	S	TBD	TBD	TBD	TBD
19	Turn on rise time	Trise	us	TBD	TBD	TBD	TBD
20	Turn off time	Toff	S	TBD	TBD	TBD	TBD
21	Turn off voltage	Voff	V	TBD	TBD	TBD	TBD
22	Resistance Imbalance	TBD		TBD	TBD	TBD	TBD
23	Output Capacitance	Cout	uF	TBD	TBD	TBD	TBD
24	Error Delay Timing	Ted	S	TBD	TBD	TBD	TBD

Wicrosemi Considering all Noise Sources over a single data and power pair . Yair Darshan , Jan 2014

Discussion



Thank You

