
# Self-configuration and Self-optimization of 4G Radio Access Networks

E. Kuehn, A. Ambrosy, D. Hofmann, C. Gerlach, M. Litzenburger Alcatel-Lucent R&I Stuttgart, Germany

# Outline


# 1. Motivation


- 2. Solution Approach for self-x - RAN self-configuration - RAN self-optimization
- 3. Architecture and Standardization Aspects
- 4. Self-configuration: Targets, Use Cases and Tasks
- 5. Self-optimization: Targets, Use Cases and Tasks
- 6. Conclusions



Main Targets: CAPEX and OPEX reduction

# Solution Approach





# Architecture and Standardization Aspects

Relevant self-x scenarios: Public Access, Office and Home

Self-x Architecture

self-x function required in OMC (network element manager) and base stations

self-x support by MS (measurements and preferably MS location info) and by base stations (measurements, Key Performance Indicators (KPIs), alarms and status reports)

self-x control and supervision via OMC

to be adapted to scenario specific RAN architecture

centralized vs. distributed self-x functional architecture is ffs.


Required interfaces:

interface between base station and OMC: tailored to specific network node implementation: to achieve maximum optimization efficiency

multi vendor support vs. OMC northbound interfaces

Standardization relevance:

configuration and reporting of MS based measurements and (if available) location info multi vendor support



# Self-Configuration Targets


**Overall Targets:** 

real plug and play for installation of new nodes and cells guaranteeing acceptable QoS when switching to operational mode

fast re-configuration in failure cases

#### Configuration functions:

set-up of neighborhood relations (cell, base station) initial resource allocation to cell and base station set-up of (initial) base station radio and RRM parameter configuration neighbor re-configuration



Self-configuration Use Cases and Tasks

Self-configuration Use Cases:

Add cell / add site scenarios, removal of cells / sites

capacity upgrade

failure cases (cell/node)

Self-configuration tasks:

automated initial configuration of cells and network nodes before entering operational mode (real plug & play) including reconfiguration of neighborhood nodes and cells: assignment of radio resources (frequency bands, interference coordination, physical channel parameters)

assignment of required identifiers (e.g. cell ID)


adaptation of predefined radio configuration parameter sets to actual location and environment, e.g.

- radio parameters (e.g. power settings)
- RRM parameters (e.g. handover parameters like thresholds, timers, hysteresis, ...)

reconfiguration of mutually depending parameters of neighbor nodes

set-up of neighborhood relations

- key function for RRM and self-x use cases (required e.g. for set-up of handover relations between cells, coverage optimization, interference coordination)
- neighborhood information required in base stations and OMC databases



Self-optimization Use Cases and Tasks

Optimization tasks (examples)

Coverage optimization

detection of areas with insufficient coverage by analysis of measurements and Key Performance Indicators (e.g. received power and call drop rates)

corrective actions:

- adaptation of transmit power settings

- adaptation of antenna direction and tilt (if available by remote control)

constraints given by the maximum tolerable interference to neighbor cells

#### Interference coordination and optimization

detection of cases with non acceptable high inter-cell interference and support of static and dynamic interference coordination schemes by analysis of measurements, Key Performance Indicators (e.g. interference level and call drop rates)

corrective actions:

- resource reassignment for interference coordination schemes
- automatic assignment of re-use factors > 1
- power setting modification
- antenna tilt and direction modification (if available by remote control)

constraints are to keep coverage in overlap areas of neighbor cells

# Self-optimization Use Cases and Tasks

#### Handover optimization

minimizing handover failure rates and avoidance of so-called ping pong handovers. Problem detection by analysis of Key Performance Indicators (handover failure rates, number of discarded PDUs and received signal level during handover, visit time distribution of target cells, ...) corrective actions:

- adaptation of handover thresholds, hysteresis and timers

includes intra and also inter technology handover

#### Load balancing

increasing the overall throughput by avoiding overload situations with increased blocking rates and insufficient provisioning of ongoing services w.r.t. QoS. Detection of unbalanced load situations by measuring usage of radio resources (e.g. total transmit power, interference, throughput) and computational power of the base stations

corrective actions:

- modification of handover parameters to force handover to neighbor cells
- redistribution of radio resources

#### Updating neighborhood relations

correction of neighbor relations according to real environment (key function for self-x and RRM)

# Conclusions

- Self-x reduces OPEX and CAPEX -- simplified processes for deployment, maintenance, and optimization
- Enabling real plug & play for new network nodes and cells
- Continuous optimization of network performance adaptation to short and long term dynamic system behavior
- Standardization required for self-x