



DMT Measurement Considerations

Test & Measurement of
Multilevel Signals for 400 GbE
Discrete Multi-Tone and PAM-X

Greg LeCheminant, Bernd Nebendahl,
Rolf Steiner

Agilent Technologies (Keysight
Technologies as of August 1)

Contributors and Supporters

Greg LeCheminant

Agilent

Bernd Nebendahl

Agilent

Rolf Steiner

Agilent

Patricia Bower

Fujitsu Semiconductor

Paul Little

Fujitsu Semiconductor

Ian Dedic

Fujitsu Semiconductor

Markus Weber

Fujitsu Semiconductor

Tomoo Takahara

Fujitsu Limited

Beck Mason

JDSU

David Lewis


JDSU

Sacha Corbeil

JDSU

Principle of DMT (Recap)


- DMT (Discrete Multi-Tone) aka OFDM (Orthogonal Frequency Division Multiplex) is widely used in wireline (ADSL, VDSL, G-fast) or wireless (DAB, DVB-T, WLAN, 3GPP LTE, WiMAX, ...)
- Effective usage of impaired channels by the use of orthogonal subcarriers with individual bit and power allocation
- Test Solutions for standardized formats are available today




picture source: IEEE302.3 Norfolk interim meeting, Fujitsu presentation

DMT Test Challenge

- Complete solution includes analysis of both the receiver and the transmitter
- This presentation: **Focus on characterization of the transmitter**
- Either optical or electrical signals can be acquired using a real time scope (see example below for a typical DMT time domain signal)



picture source: IEEE302.3 Norfolk interim meeting, Fujitsu presentation



typical DMT signal

Conclusion: The raw measurement in time domain yields very limited information aside from an upper-bound to the optical modulation amplitude!

Useful information is obtained through post processing the time record


DMT Test Receiver Requirements

- To receive the signals the bandwidth of the digitizer (real-time sampling scope) should be at least the Nyquist frequency of the DAC that was used to generate the DMT signal. For a 63 GS/s DAC (number from JDSU's presentation) the bandwidth of the digitizer should be ≥ 31.5 GHz
- Scope vertical resolution equal to the resolution of the DAC generating the signals is considered to be sufficient (typically 8 bit)
- Sampling time to be able to decode n_{Sym} DMT symbols ($n_{\text{FFT}} = \text{FFT size}$)

$$t_{\text{sampling}} = 1/f_{\text{DAC}} \cdot n_{\text{Sym}} \cdot n_{\text{FFT}}$$

- required number of samples

$$n_{\text{sampling}} = f_{\text{ADC}} \cdot t_{\text{sampling}}$$



DMT signal example:

$$n_{\text{Sym}} = 50$$

$$n_{\text{FFT}} = 512$$

$$f_{\text{DAC}} = 63 \text{ GS/s}$$

$$t_{\text{sampling}} = 406 \text{ ns}$$

$$f_{\text{ADC}} = 80 \text{ GS/s}$$

$$n_{\text{sampling}} = 32480$$

DMT Analysis Software

- Physical layer testing and analysis of DMT signals requires to know bit allocation, subcarrier allocation, FFT size, cyclic prefix, system sampling frequency, and other parameters
 - Without standardization any DMT link start sequence should be excluded from physical layer testing
- **Because we are lacking a standard a general purpose DMT (OFDM) decoder is required to be able to analyze the signals**

DMT Analysis fundamentals

- Resample the data to the DMT system sample frequency
- Find the FFT frames using a suitable synchronization method (for non-burst signals w/o preamble take advantage of cyclic prefixing of the FFT frame)
- FFT on raw waveform record, the resulting coefficients are the raw complex amplitudes of each subcarrier
- Add a linear phase (mathematically equal to adjusting the sampling phase) to correct the phase of the known pilots
- Equalize for amplitude and phase response, take advantage of the fact that the modulation is known for pilots and data subcarriers
- Extract quality metrics like EVM
- Virtually identical to methods used to analyze signals in LTE, WLAN 802.11, WiMAX 802.16
- Analysis tools already exist and require minor modification for DMT analysis

DMT Analysis Results

Typical results available from T&M OFDM decoders

- constellation diagram per subcarrier (SC)
- channel response (amplitude and phase from equalizer)
- received spectrum and time domain waveform
- received data stream (→ path to BER testing)
- error vector magnitude (EVM) vs. time
- EVM per SC
- ...

**For physical layer testing EVM is a widely used metric
also in other OFDM based standards**

DMT Analysis Software Example

Example (Simulation)

- 63 GS/s system frequency
- complex FFT Size 512
- variable bit allocation
- colors encode modulation from QAM 64 (green), QAM 32 (dark blue), QAM 16 (light blue), QAM 8 (red) to QPSK (orange)
- two pilot tones (QPSK, white)
- ADC sampling frequency 80GS/s, 8 bit vertical resolution

Traces (top row)

A: constellation (all SCs)

F: received data stream

E: Data Info

G: Quality Metrics


Traces (bottom row)

H: Error Vector vs. Time

C: Error Vector vs. Frequency

B: Received Spectrum

D: Received Time Domain Signal



Note: Analysis performed using existing software analysis tools

DMT transmitter measurement conclusions

- DMT signals require different test and analysis methods compared to more common optical communications signals
- Existing test solutions developed for similar technologies can be leveraged for DMT analysis
- If 802.3bs employs DMT, analysis is simplified if specific test modes are allowed that minimize or do not require link training to achieve a specific transmitter state

Extending DMT measurement process to PAM

- Physical layer testing and analysis of PAM-X signals requires knowledge of the number of signal levels, symbol rate, and possibly time domain pulse shaping if applicable
- Oscilloscopes will evolve to provide fundamental PAM-N analysis as system and component designers along with T&M providers determine essential metrics
- DMT analysis process configured with available custom IQ decoders allows PAM-X decoding

•

PAM-X Analysis Results

Typical results available from T&M Custom IQ decoders

- channel response (amplitude and phase from equalizer)
- received spectrum and time domain waveform
- received data stream (→ path to BER testing)
- magnitude error vs. time
- SNR
- Likely provides a complementary set of measurements to those provided by sampling and real-time oscilloscopes

PAM-4 Analysis Software Example

Example (Measurement)

- 10 GBaud symbol rate
- NRZ-OOK with no pulse shaping

Traces (top row)


A: Color coded eye diagram

B: signal metrics and received data stream

Traces (bottom row)

C: Received signal spectrum

E: Received Time Domain Signal



Note: Using existing software tools

Conclusion

- Test and solutions for DMT signals are available today (and can be extended to PAM-X)
- Support will be provided to the standard to ensure testability of the signals.