

INSERT THIS TEXT AT THE END OF 169.5.4, AFTER TABLE 169-7:

The MPD's response to the DISCOVERx events informs the MPSE of the MPD Type. The first two DISCOVERx events allow the MPSE to calibrate. During event 1, all MPDs respond by drawing $I_{MPD_discover}$. During event 2, all MPDs do not respond (i.e. continue to draw I_{MPD_mark}). During event 3, Type 0 MPDs respond and Type 1 and Type mixed MPDs do not. During event 4, Type 1 MPDs respond and Type 0 and Type mixed MPDs do not. During event 5, Type mixed MPDs respond and Type 0 and Type 1 MPDs do not. An MPD responds only once during events 3, 4, and 5. Table 169-X shows the MPD response for each Type of MPD to each DISCOVER_LOWx event.

Table 169-X

DISCOVERx Event 1	DO_DISCOVERY1				
DISCOVERx Event 2	DO_DISCOVERY2				
DISCOVERx Event 3	DISCOVERY_LOW_TYPE_0				
DISCOVERx Event 4	DISCOVERY_LOW_TYPE_1				
DISCOVERx Event 5	DISCOVERY_LOW_TYPE_MIXED				
Discovery event:	1	2	3	4	5
Type 0	1	0	1	0	0
Type 1	1	0	0	1	0
Type Mixed	1	0	0	0	1