

PMA for Asymmetric MGBASE-T1

Hossein Sedarat

1/30/2019

ETHERNOVIA

Interest in Asymmetric Mode

From 802.3ch meeting on 1/19:

- Straw Poll #5: Should the Task Force investigate asymmetric framework with the goal of having the feature scoped out in March:

Yes: 20

No: 6

- Straw Poll #6: If the asymmetric framework added x months to the P802.3ch timeline would you support it?

x = 9: 2

x = 3: 15

x = 6: 7

=> A lot of interest as long as the spec comes together quickly

State of 'Asymmetric Mode'

- Current active discussion on PCS:
 - http://www.ieee802.org/3/ch/public/jan19/Lo_3ch_01_0119.pdf
 - http://www.ieee802.org/3/ch/public/nov18/souvignier_3ch_02_1118.pdf
- Some preliminary ideas on PMA:
 - http://www.ieee802.org/3/ch/public/jul18/souvignier_3ch_01a_0718.pdf

Agenda

To propose a PMA frame-work for low data-rate mode


1. That can coexists asymmetrically with nominal rate on opposite direction of a link
2. That consumes low power
3. For a quick consensus, reuses as much as what is already debated and defined in the current draft
 - Modulation
 - Baud-rate, bandwidth and PSD
 - Precoding
 - Bit-mapping
 - FEC: Reed-Solomon code
 - Frame structure

EEE for Asymmetric Mode

- EEE frame-work is well-suited for asymmetric mode as it offers:
 - Asymmetric operation
 - A low-power mode
 - Signaling is already debated and is almost finalized
 - Bonus: seamless transition between normal data mode and low-power mode


Low-Power Idle (LPI)

- During LPI, the transmitter is mostly quiet but periodically sends a short *Refresh* training signal so that the link-partners remain synchronized and are able to track variations in channel and noise
- LPI is terminated and normal data mode starts with *Alert* followed by *Wake* frames





Low-Power Data (LPD)

- A new ordered set or control character at XGMII interface signals the transition to Low-Power Data (LPD) mode
- LPD is similar to LPI, except every N cycles of Q-R, a new Special signal replaces Refresh
 - The Quiet time that follows the special signal is shortened to preserve the Q-R period



Special LPD Signal

- Begins with 1 or more Refresh for quick training
- Followed by 0 or more Wake for graceful transition to data
- Ends with 1 or more RS data frames (using normal transmit functions: RS code, scrambler, precoding, PAM4, etc.)



Data Rate and Power

- The data rate in fast (R_h) and slow (R_l) directions are related as

$$R_l = \frac{N_d}{100 \times N} R_h$$

100 frames in every LPD period

- The power in slow mode (P_l) may be roughly expressed in terms of the corresponding power in fast (P_h) and EEE (P_e) modes as

$$P_l = \left(1 + \frac{N_w}{N_d}\right) \frac{R_l}{R_h} P_h + \left(1 + \frac{N_r - 1}{N}\right) P_e$$

Overhead of Wake

Overhead of long Refresh

Latency and Power Trade-offs

- The data rate depends on the ratio of N_d and N
- It is more power efficient to maximize N for minimum N_d
- But latency grows with N

Resisting Noncritical Innovations!

- It is possible to send data with PAM2 modulation
 - 👉 It may shorten the training time (Refresh)
 - 👉 It doubles the data transmission time
 - 👉 We have to spend time to figure out how to do data over PAM2
 - ➡ Use PAM4 modulation for data
- It is possible to design a new RS code for a shorter data frame
 - 👉 It may help with latency
 - 👉 Overhead of turning on/off data-path may have negative power impact
 - 👉 We have to spend time to figure out how to do data over PAM2
 - ➡ Use integer multiples of RS data frame

Example

- Choose $N_r = N_w = 1$, resulting in $P_l = 2 \frac{R_l}{R_h} P_h + P_e$

R_h	R_l	N	N_d
10 G	10 M	10	1
5 G	10 M	5	1
2.5 G	10 M	5	2
10 G	100 M	1	1
5 G	50 M	1	1
2.5 G	25 M	1	1

Is 10 Mbps Sacred?


If not,

⇒ Choose $N = N_r = N_d = N_w = 1$

LPD data-rate: $R_l = S \times 100 \text{ Mbps}$

(S : scaling factor for baud-rate as defined in draft 1.0)

LPD power: $P_l \approx P_e + 0.02 \times P_h$



What about OAM?

- OAM may be loaded on either or all of Refresh, Wake and Data frames
- It is beneficial if Refresh and Wake are skipped so that they remain completely known signal


⇒ Use data frames to carry OAM messages during LPD

Conclusions

- LPD is proposed as a simple frame-work, based on EEE, to support asymmetric mode

LPD data-rate: $R_l = S \times 100 \text{ Mbps}$

LPD power: $P_l \approx P_e + 0.02 \times P_h$



- Reuses mostly what is already debated and defined in the spec
 - Least impact on the timeline of the task force
 - May not be the most optimal but it is not too far off from it either