



# IEEE 802.3az

# Energy Efficient Ethernet

## Task Force Update

Presented to the P802.1 Working Group

Denver, CO  
July 16, 2008

Mike Bennett  
[mjbennett@ieee.org](mailto:mjbennett@ieee.org)

# Acknowledgement

- Thanks to Dan Dove, Rob Hays, and David Law for their contributions

# Discussion


- Brief overview of Energy Efficient Ethernet (EEE)
- IEEE P802.3az – current status
- Things to consider - latency

## Briefly, what is EEE?

- EEE is a method to facilitate transition to and from lower power consumption in response to changes in network demand
  - In the process of being defined for these copper PHYs
    - 100BASE-TX (Full Duplex)
    - 1000BASE-T (Full Duplex)
    - 10GBASE-T
  - Expecting to adopt proposals for backplane PHYs this week
    - 10GBASE-KR
    - 10GBASE-KX4
    - 1000BASE-KX
  - Uses Low Power Idle (LPI) to save energy

# What is Low Power Idle?

- Concept: Transmit data as fast as possible, return to Low-Power Idle
- Saves energy by cycling between Active and Low Power Idle
  - Power reduced by turning off unused circuits during LPI
  - Energy use scales with bandwidth utilization




# What is Low Power Idle?

## ■ A closer look

□ We've been talking about  $T_w$  values under 20 usec

Term	Description
Sleep Time ( $T_s$ )	Duration PHY sends Sleep symbols before going Quiet.
Quiet Duration ( $T_q$ )	Duration PHY remains Quiet before it must wake for Refresh period.
Refresh Duration ( $T_r$ )	Duration PHY sends Refresh symbols for timing recovery and coefficient synchronization.
PHY Wake Time ( $T_w\_PHY$ )	Duration PHY takes to resume to Active state after decision to Wake.
System Wake Time ( $T_w\_System$ )	Wait period where no data is transmitted to give the receiving system time to wake up.




# A system view

## ■ Outside the scope of our work


- ❑ Control policy
- ❑ System power savings

## ■ In scope

- ❑ PHY power savings
- ❑ Auto-negotiation
- ❑ Management
- ❑ Protocol to communicate parameter changes



# A system view (switch centric)



Switch MAC, NSE, Memory are a good portion (~3x/port) of energy consumption for most networking link technologies.

Powering-down portions of these circuits provides a two-fold benefit


- 1) Reduces energy used
- 2) Provides opportunity to shut-down other infrastructure (DC/DC, Fans, etc)

Reasonable estimates show that **~1.5W- 3W/port** can be reduced in infrastructure

What to power-down and how to do it, is outside the scope of 802.3, but providing means to communicate when to power-down and when to resume operation may be appropriate for 802.3 to address


# Link partner communication

- Will use auto-negotiation to notify link partner of EEE capabilities
- Will use LLDP to notify link partner of parameter changes
  - E.g. control policy
    - User can choose energy savings preferred over performance or vice versa



# LLDP

- We'll need to define LLDP MIB extension and TLVs as well as an EEE MIB



# Current status

- **We've adopted several proposals for our baseline**
  - Reduced Amplitude 10BASE-T
  - Low Power Idle (LPI) for 100BASE-TX
  - LPI for 1000BASE-T
  - LPI for 10GBASE-T
  - Use of LLDP to communicate between link partners after auto-negotiation
- We have an editor's draft incorporating these proposals

# Current status

- **We're considering backplane proposals for our baseline**

- 10GBASE-KR

- 10GBASE-KX4

- 1000BASE-KX

- The work is being done, planning to add an objective

- Assuming we get through the remaining proposals this week


- We'll bring in the material from the new proposals for review in September

- Focus on

- filling in TBDs and holes in the draft

- Possibly Modifications to the Reconciliation Sublayer and MIBs

# 802.3az timeline – adopted 2008-03-20



# Things to consider

## ■ Latency

- EEE operational mode adds additional latency to be considered by the network designer
- When at Low Power Mode, PHY device is not available immediately for data transmission request.
  - System has to wake it up by sending normal idle code on the MAC interface.
  - Following IDLE code reception on the MAC interface, PHY starts waking up process.
  - The max PHY recovery time  $T_w$  is different for different PHY types

# Things to consider

## ■ Latency

- We will specify the maximum values of  $T_w$  as soon as we have agreed on them

Table 4—

Protocol	$T_w$
10GBASE-KR	TBD
10GBASE-KX4	TBD
10GBASE-T	TBD
1000BASE-T PHY	TBD
100BASE-TX	TBD

# Things to consider

## ■ LLDP

- What is the best approach to specifying the EEE LLDP MIB and TLVs?



Thank You!






Back-up



# Things to consider

- LPI is “architecture agnostic”
  - It will work on a serial interface
  - It will work on a multi-channel interface

## Layer Diagram



# Objectives

- ❑ Define a mechanism to reduce power consumption during periods of low link utilization for the following PHYs
  - 100BASE-TX (Full Duplex)
  - 1000BASE-T (Full Duplex)
  - 10GBASE-T
  - 10GBASE-KR
  - 10GBASE-KX4
- ❑ Define a protocol to coordinate transitions to or from a lower level of power consumption
- ❑ The link status should not change as a result of the transition
- ❑ No frames in transit shall be dropped or corrupted during the transition to and from the lower level of power consumption
- ❑ The transition time to and from the lower level of power consumption should be transparent to upper layer protocols and applications
- ❑ Define a 10 megabit PHY with a reduced transmit amplitude requirement such that it shall be fully interoperable with legacy 10BASE-T PHYs over 100 m of Class D (Category 5) or better cabling to enable reduced power implementations
- ❑ Any new twisted-pair and/or backplane PHY for EEE shall include legacy compatible auto negotiation