Enhance Downlink Positioning in WiMAX

Document Number: IEEE C802.16m-08/1105

Date Submitted: 2008-09-05

Source: Shu Wang, Ki-Dong Lee and Sang G. Kim LG Electronics Mobile Research USA

Email: swang@lge.com

Venue:

IEEE Session #57, Kobe.

Base Contributions:

None

Re: Call for Contributions on Project 802.16m System Description Document (SDD): PHY & MAC aspects of enhanced LBS

Purpose: Discussion and Approval

Notice:

This document does not represent the agreed views of the IEEE 802.16 Working Group or any of its subgroups. It represents only the views of the participants listed in the "Source(s)" field above. It is offered as a basis for discussion. It is not binding on the contributor(s), who reserve(s) the right to add, amend or withdraw material contained herein.

Release:

The contributor grants a free, irrevocable license to the IEEE to incorporate material contained in this contribution, and any modifications thereof, in the creation of an IEEE Standards publication; to copyright in the IEEE's name any IEEE Standards publication even though it may include portions of this contribution; and at the IEEE's sole discretion to permit others to reproduce in whole or in part the resulting IEEE Standards publication. The contributor also acknowledges and accepts that this contribution may be made public by IEEE 802.16.

Patent Policy:

The contributor is familiar with the IEEE-SA Patent Policy and Procedures:

< http://standards.ieee.org/guides/bylaws/sect6-7.html#6> and < http://standards.ieee.org/guides/opman/sect6.html#6.3>.

 $Further information is located at < \underline{http://standards.ieee.org/board/pat/pat-material.html} > and < \underline{http://standards.ieee.org/board/pat/pat-material.html} > .$

Enhance Downlink Positioning in WiMAX/16m

Shu Wang, Ki-Dong Lee and Sang G. Kim LG Electronics Mobile Research USA

Outline

- 802.16m SRD
- Introduction to LBS
 - FCC E911 and EU E211
 - Downlink or Uplink Positioning
- Hearability Issues in Downlink Positioning
- Proposed Downlink Positioning Techniques for WiMAX
- Proposal I: Downlink Silent Period
- Proposal II: LBS Zone and Downlink LBS Pilots
 - LBS Downlink Pilot Design
- Proposed ToC
- Proposed SDD Text

802.16m SRD

7.6 Location-based services performance

 IEEE 802.16m systems (this may include MS, BS, or both depending on the solution) should provide support for LBS. IEEE 802.16m systems should satisfy the requirements in Table 15.

Feature	Requirement	Comments
Location determination latency	< 30 s	
Handset-based position accuracy (in meters)	50 meter (67%-tile of the CDF of the position accuracy) 150 meter (95%-tile of the CDF of the position accuracy)	Need to meet E911 Phase II Requirements
Network-based position accuracy (in meters)	100 meter (67%-tile of the CDF of the position accuracy) 300 meter (95%-tile of the CDF of the position accuracy)	

Table 15–Location-based service requirements

Introduction (1/2): E911 and E211

FCC Enhanced 911

- Phase I: Within six months of a request by a Public Safety Answer Point (PSAP), the carrier shall provide PSAPs with the telephone number and the cell site location for this 911 call.
- Phase II: Within six months of a request by a PSAP, more precise location information, such as the latitude and longitude of the caller, shall be provided.
 - For network-based solutions, 100 meters for 67%; 300 meters for 95%.
 - For handset-assisted solutions, 50 meters for 67%; 150 meters for 95%.
- Phase II Compliance Status: In August 2007, FCC fined three carriers, Sprint Nextel, Alltel and US Cellular, \$2.8M for failing to meet the mandate (December 2005) to provide E911 service to 95 percent of their networks.

EU Location-Enhanced 112

- In 2000, the EU launched activities for enhanced 112 (E-112) and CGALIES (the Coordination Group on Access to Location Information for Emergency Services) is initiated.
- In September 2002, an EMTEL ad hoc group under the ETSI OCG (Operational Coordination Group) was set up to look at standardization requirements.
- In July 2003, the EU issued a Recommendation for the Europe-wide implementation of the location-enhanced 112.


Mission Unaccomplished.

It is not a easy job to completely satisfy the mandates alone.

Introduction (2/2): Downlink or Uplink Positioning


- There are certain tradeoffs between downlink and uplink approaches for location services.
- Most downlink approaches require mobiles to be explicitly involved into positioning procedures.
 - The DL pilot channel power usually is very strong and consistent.
 - Additional feedback channel is required.
 - Positioning feedback channel may be shared with other channels.
 - More positioning delay may happen.
 - In general, mobile has limited resources and knowledge.
- Uplink approaches impose less burden on the mobile side.
 - The network side usually has enough resources for positioning.
 - Low latency with no feedback channel necessary.
 - Flexible and standards-independent.
 - The transmit signal power by mobile usually is not strong.

Hearability Issues in Downlink Positioning




- There are hearability issues for positioning with TDOA methods. It is also a challenge for network planning.
 - Inside the cell, the serving base station drowns the signals from distant base station.
 - In the cell edge, the signal power from nearby base stations are close to each other and interferes each other.
- In addition for indoor positioning and Femto cell synchronization, it is necessary to provide additional mechanisms for downlink pilot/preamble measuring.

Proposed Downlink Positioning Techniques for WiMAX



The near-far problem can be mitigated by the technique, Downlink Silent Period (DSP), where the serving BS intentionally control its transmission during some preamble periods of neighbor BS's.

The cell edge issue can be mitigated by the technique, LBS zone and LBS pilots, where each involved BS sends an unique positioning pilot that is orthogonal to the others.




Proposal I: Downlink Silent Period (DPS) (1/2)

- Downlink Silent Period (DSP) is a technique proposed for WiMAX network, where base station's transmissions are specially controlled for a short period of time.
 - The serving BS can keep silent, for example, on some of its preamble/data periods and also inform mobiles about this.
 - A served mobile can clearly measure the neighbor base station's pilot signals during the DSPs of serving BS.
 - DSP helps maximize the hearability of distant pilots.
- Before a base station start applying DSP on its transmission, it will inform the served mobiles the details of the next DSP.
 - This can be implemented independently by each base station
 - Or it can be done with some coordination among multiple base stations. Therefore there will be fewer collisions on applying DSP between base stations.


Proposal I: Downlink Silent Period (DPS) (2/2)

- The application of DSP may depend on
 - The request of the served mobiles.
 - The request of neighbor base stations
 - The request from the network, mobile location center (MLC) or positioning determination entity (PDE).
- DSP for two preamble design scenarios
 - Synchronous Preambles, where the preambles from the nearby BS's are sent at the same time. In this case, DSP helps mitigate the interference between the preambles and maximize the hearability of preamble.
 - Asynchronous Preambles, where the preambles from the nearby BS's aren't sent at the same time. In this case, the serving BS applies DSP on the symbol sequences where the nearby BS's preambles are being broadcasted.
- DSP can be used for increasing the hearability of any signal from neighbor base station, which includes preamble and other pilots.

Proposal II (1/2): LBS Zone and LBS Pilots



Distributed Allocation Example



Localized Allocation Example

- The network reserves certain resources for transmitting LBS pilots.
 - It may be called LBS pilot zone
- Each BS has its own LBS pilot waveform with a unique positioning code.
- All LBS pilots are orthogonally multiplexed and distinguished from each other with time, frequency position and scrambling positioning codes.

Proposal II (2/2): LBS Pilot Design

- LBS pilot design can reuse the existing or future uplink ranging channel design.
 - One option: reuse the existing 16e ranging sequences
 - The PRBS generator shall be initialized by the seed b14...b0 = 0,0,1,0,1,0,1,1,s0,s1,s2,s3,s4,s5,s6, where
 - s6 is the LSB of the PRBS seed, and
 - s6:s0 = UL_PermBase, where s6 is the MSB of UL_PermBase.
 - The length of each ranging code is 144 bits. The number of available codes is 256.
 - For example, the first 144 bit code obtained by clocking the PN generator as specified, with UL_PermBase = 0, the first code shall be 011110000011111...00110000010001... The next ranging code is produced by taking the output of the 145th to 288th clock of the PRBS generator, etc.
 - The bits are mapped to the subcarriers in increasing frequency order of the subcarriers.
 - It is open for future discussions.
- The positioning of LBS pilot zone can be assigned in the same way as MBS zone.

Proposed ToC

- Support for Location Based Services
 - Location Based Services Overview and Protocol Structure
 - Physical Layer Support for Location Based Services
 - Possible Positioning Technologies
 - Physical Layer Enhancements for Location Based Services
 - Physical Layer Downlink Enhancements
 - » LBS Zone and LBS Pilots
 - » Downlink Silent Period
 - » GPS and Galileo Positioning Assistance
 - Physical Layer Uplink Enhancements
 - MAC Layer Support for Location Based Services
 - Location Based Services (LBS-ADV) message

Proposed Text (1/3)

- XX Support for Location Based Services
 - This subclause provides additional enhancements and mechanisms to coordinate the collection, generation, and reporting of information used to determine MS location (e.g. RSSI, CINR, Time Difference of Arrival (TDOA), Time of Arrival (TOA), ...). Reporting of BS location information is also described.
 - XX.1 Cell-Id Based Approach
 - Cell-Id is a location determination scheme that a MS periodically report the id of its serving cell with the
 assumption that the approximate location of this MS is the center of the serving cell. There are two
 types of cell-Id based enhancements.
 - Cell-Id with RSSI A MS report RSSI data in its channel quality measurements of its serving BS. The serving BS may predict the distance between the MS and the serving BS. This prediction can be used to calibrate the cell-Id based positioning
 - Cell-Id with Timing Advance The serving BS periodically measure the delay between a MS transmit time and
 receive time and use this measurement to predict the distance between the MS and serving BS. This prediction can
 be used to calibrate the cell-Id based positioning
 - XX.2 Time Difference of Arrival (TDOA)
 - TDOA is a location determination scheme that measures the difference of time arrival for packet transmission between a MS and multiple BSs. There are two types of TDOA - Downlink TDOA (D-TDOA) and Uplink TDOA (U-TDOA) based on whether the measurements are performed in the MS and the BS, respectively.
 - D-TDOA MS may report D-TDOA data in the Relative Delay parameter in MOB_SCN-REP message that
 indicates the delay of DL signals from a neighbor BS relative to the serving BS. MOB_SCN-REP also reports RSSI
 and CINR of DL signals from neighbor BS that can be used for MS location estimation. During SBC-REQ/RSP
 based capability negotiation, HO Trigger metric support (see 11.8.7) indicates which trigger metric that the MS
 supports.
 - U-TDOA As opposed to D-TDOA that is reported each time MS scanning is completed, U-TDOA enables BS to initiate U-TDOA measurement when it is needed. Annex L describes two algorithms to show the U-TDOA measurement through the coordination of MS, serving BS, and one or more neighbor BS for wireless broadband networks: the General U-TDOA Method, for any FRF (Frequency Reuse Factor); and the Special U-TDOA Method, for FRF = 1.

Proposed Text (2/3)

- Downlink Silent Period.
 - Each 16m base station shall be able to control the transmission power of its frequency and time resources for helping the served 16m subscribe stations measure the pilots or preambles of neighbor base station or location reference unit (LRU). LRU is any equipment which periodically or constantly broadcast pilot signals for positioning purposes.
 - The serving 16m base station can low or silent its preamble transmission.
 - The serving 16 base station can low or silent the transmission of some portions of its data frame.
 - Each 16m base station shall be able to inform each served mobiles when it will start control its transmission power and which channel resource it will control.

Proposed Text (3/3)

LBS Zone

- LBS Zone is a special block of time and frequency resource assigned for help the served mobiles to performance positioning operation.
- Each base station can have its own LBS zone independently. Or there are multiple base station share the same LBS zone during their transmission.
- The assignment of LBS zone can be dynamic or periodic.
- The position and size of LBS zone are informed and available to each served subscribe station.

LBS Pilots

- LBS pilots are a set of orthogonal pilots transmitted from base stations to subscribe stations for positioning purposes.
- LBS pilots are transmitted inside LBS zone.
- Each involved base stations has its own unique LBS pilot, which is transmitted through a different set of symbol periods or frequency subcarriers from other LBS pilots. Therefore there is no collision between any pair LBS pilots.

Reference

- IEEE 802.16 Broadband Wireless Access Working Group IEEE 802.16m System Requirements. http://wirelessman.org/tgm/docs/80216m-07_002r4.pdf
- P802.16Rev2/D4 (April 2008), Part 16: Air Interface for Broadband Wireless Access Systems
- Shu Wang, Jungwon Min and Byung K Yi, "Location Based Services for Mobiles: Technologies and Standards", Tutorial#25, IEEE International Conference on Communication (ICC), May 23, 2008, Beijing, China.
- Shu Wang, Jungwon Min, Li-Hsiang Sun, "Enhanced Location Based Support in cdma2000", 3GPP2 TSG-C NTAH, Osaka, Japan, May 2008.